



45 Degree Bay Windows



- Using a metal tape measure, take the measurements of A, B & C at the top of the bay window where the blinds will actually be fitted. Measure right into both corners where the roller blinds will butt up together. It is preferred to have the blinds butting up, so that when the blinds are closed, there is as small a gap as possible between the roller blinds. Then check the same measurements at the bottom of the window to make sure the blinds will fit when down.
- Once you have all three measurements make the following deductions from the width of each blind:
 - Blind A** - deduct **50mm** from the width, eg. if the width of the blind is 1000mm after deductions it will be 950mm.
 - Blind B** - deduct **24mm** from the width, eg. if the width of the blind is 1000mm after deductions it will be 976mm.
 - Blind C** - deduct **24mm** from the width, eg. if the width of the blind is 1000mm after deductions it will be 976mm.
- Once you have made these deductions, on the ordering page enter the dimensions and select Outside Recess (exact blind size) from the blind location options drop down. This is so we will not make any further deductions to the ones you have already made, except for the brackets and controls ends. So the sizes you specify after deductions will be the width of the blind from the outside of one bracket to the other. So when fitted the brackets will butt up together to give you the smallest gap possible. Note the fabric will be 34mm narrower than these sizes to allow for the control ends, but we will make these allowances for you. There is no need to make any deductions to the drop of roller blinds.

90 Degree Bay Windows



- Follow the measuring instructions as above and then make the following deductions from the width of each blind:
 - Blind A** - deduct **4mm** from the width, eg. if the width of the blind is 1000mm after deductions it will be 996mm.
 - Blind B** - deduct **66mm** from the width, eg. if the width of the blind is 1000mm after deductions it will be 934mm.
 - Blind C** - deduct **66mm** from the width, eg. if the width of the blind is 1000mm after deductions it will be 934mm.

Note: If there are any obstructions in the bay window such as upvc makeup, wood quadrant, tiles, handles or dado rails then make appropriate allowances for these obstructions, so the blinds can be operated freely and fit correctly.